

A Little Care Goes a Long Way

Bring out the best of your KompacTop and KompacWall with a few easy tips to ensure your favourite surfaces bring you years of quality performance.

Cautionary Notes and Cleaning Tips

Everyday Cleaning

To clean your KompacPanel surface, a quick wipe-down using a clean cloth or sponge with a mild soap or detergent will do the job. Rinse the surface thoroughly with warm water and wipe dry after.

Treating Stains

Treat spills and stains using a mild household cleaner or detergent and a soft bristled brush.

For tougher stains, use a paste of baking soda and water and apply with a soft bristled brush.

Avoid excessive or forceful scrubbing which could damage the surface.

For stubborn stains, apply nail polish remover and let it stand for no more than two minutes. Rinse the surface thoroughly with warm water and wipe dry. Repeat only if colour of surface is not affected.

Cautionary Notes

Avoid direct contact of heat with countertops. Always use a heat shield or pad, when using hot pans and heat-producing appliances. Extreme heat can cause cracking and blistering.

Avoid contact with harsh chemicals. In the event of contact, wipe immediately and rinse several times with warm or soapy water.

Avoid using acidic, harsh or abrasive cleaning solutions and tools.

Avoid water ponding on the top surface at all times.

Prolonged exposure of the KompacPanel surface to bleach will cause discolouration.

Do not place KompacPanels outdoors or in places with direct UV lighting. Over time, the colour and shade of the panels may suffer from the effect of the sun's rays.

Recommended Cleaning Product and Method

Origin of Dirt	Recommended Cleaning Product and Method
Fruit juice, liquor, milk, tea, coffee, jam, wines and spirits	Wash using soft sponge with water
Animal and crop fats, sauces, dry blood, eggs	Wash with hot water and soap, rinse well and dry with cotton cloth
Smoke black, jelly, vinyl adhesives, watercolor paints, organic residues	Wash with hot water and soap, rinse well and dry with cotton cloth
Vegetable oils, markers, wax, residual solvent marks	Clean using a cotton cloth with alcohol or acetone, rinse well with cold water and dry
Linseed oil	Remove using cotton cloth with acetone
Neoprene adhesives	Remove using cotton cloth with thinner
Synthetic oil paints	Remove using cotton cloth with thinner
Silicon traces or residues	Remove gently using wooden or plastic scraper
Limescale	Remove using detergent with low content of citric or acetic acid, maximum of 10% only

Disclaimer

The KompacPlus Care Guide Manual generally aims to give knowledge of the KompacPanels, its end use, technical aspects and how to care for it and in no way account for any form of warranty or representations, either expressed or implied, of its fitness for a specific purpose and the processes required for that purpose.

Moreover, KompacPlus shall not be held liable for any damage caused from relying upon this care guide. The KompacPlus products' suitability in the user's design and application must be verified by the user and corroborated with professionals. KompacPlus reserves the right to make any amendments and changes, whether it be on the product designs or simple product descriptions at any time. The copyright of this care guide belongs to KompacPlus and its manufacturers.

Singapore HQ

KompacPlus Pte Ltd
 280 Woodlands Industrial Park E5
 #04-15 Harvest @ Woodlands
 Singapore 757322
t: (65) 6842 0335
f: (65) 6842 0353

Malaysia

KompacPlus Industries Sdn Bhd
 No. 3-01 Jalan Pertama 2
 Pusat Perdagangan Danga Utama
 81300 Skudai Johor, Malaysia
t: (60) 07 558 9878
f: (60) 07 557 9878

If you would like to obtain more information, discuss a potential project or collaborate with us, please write to us at enquiry@kompacplus.com.

We would love to hear from you.

kompacplus